



Recommended List of Rutland Electric Fencing Components

Item	Description	REF Part No
Lead Out Cable	Use to connect live and earth wire on fence	17-128
Fence Line Wire Clamps	Use to attach lead out cable to fence line	18-172
7 Strand Galvanised	400 metre spool of galvanised fence wire	19-101
Treated Wood Posts	Use to create perimeter and wire spacing	N/A
Wood Screw Insulators	For attaching fence line to wood posts	15-129
Strain Insulator	Use on end/corner posts to secure fence line	16-122
Strainers	For removing slack from the fence line	18-184

Monitor the fence voltage regularly and ensure it is a minimum of 3000 volts at all points on the fenceline.

Test the earth system regularly and ensure a maximum of 400 volts. If greater than this, add more earth stakes until it is brought down.

Use a quality tester to check fence and earth voltages such as 14-172.